

LEFT SIDE VIEW

FRONT VIEW WITH OUTER DOOR OPEN


FRONT VIEW WITH INNER PANEL REMOVED

RIGHT SIDE VIEW


FOR NON-STANDARD OPERATING PRESSURES,  
 SPECIAL LABELS ARE ATTACHED.

NOTES:

1. MIXER MUST BE MOUNTED IN VERTICAL POSITION.
2. ALL DIMENSIONS IN INCHES UNLESS OTHERWISE NOTED. DIMENSIONS ARE APPROXIMATE.
3. STANDARD OPERATING PRESSURES ARE SHOWN. CONSULT DATA SHEET FOR ACTUAL OPERATING PRESSURES.



VIEW OF BACK OF INNER PANEL  
 SHOWING ANALYZER



DIMENSIONS FOR MOUNTING

REVISIONS	BY	DATE
H	GAR	4-11-08
G	GAR	5-27-04
F	KGR	4-22-03
E	DMR	10-28-02
D	GAR	6-7-02
C	DMR	11-30-98
B	DMR	3-19-98
A	KB	1-15-98

**THERMCO** INSTRUMENT CORPORATION  
 LA PORTE, INDIANA USA

SCALE: N.T.S. B. M. NO. S. O. NO. DRAWN BY: DB  
 DATE: 11-14-95 CUSTOMER: APPROVED BY:  
 TITLE: INSTRUCTION DRAWING FOR MODEL 9520 GAS MIXER SUPERSEDES: 4-10374  
 DRAWING NUMBER: 2-11087

7/8" HOLE FOR  
 CUSTOMER'S  
 ELECTRICAL  
 CONNECTION

OPTIONAL  
 220 VAC TRANSFORMER

POWER TERMINAL BLOCK  
 (220 VAC VERSION)

OPTIONAL FUSES FOR 220 VAC VERSION  
 0.5 AMPERE FUSES  
 3AG (1/4" X 1 1/4")  
 FAST-ACTING